

Quick Set-Up Instructions – RC1000

The RC1000 can be configured via either USB or via the RJ45 Ethernet connection with WinDiscovery for use with either TCDS (SMPTE) time code displays, NTDS (Network Time Displays) from Masterclock.

Quick-Start Instructions

Keep the power disconnected until the last step.

Make any desired input and output connections to the DB25 connector labeled CONTROL using either your own cable or an optional DB25 to terminal block breakout adapter (included with your RC1000). See the “Connections” section of your user manual for additional details and pinout for the DB25 connector.





Connect the RC1000 device to your LAN (Local Area Network) hub/router/switch using Cat5 cable making the connection to the RJ45 connector labeled ETHERNET.

Apply power: insert the supplied AC/DC power supply module into an appropriate AC power source and the DC power connector into the male Switchcraft-style locking power socket on the rear of the unit labeled DC IN +8 to28 VDC.

Status LEDs

Monitor the front panel display for power up status. When power is first applied the initial sequence of the front panel LEDs are:

- Chan A and Chan B, 6-digit LEDs will show all 8s, then will display time and/or date according to the settings the user has made.

Configuration

The RC1000 is configured over the network via software control using either Telnet, SSH or WinDiscovery.


MASTERCLOCK INC. 5-YEAR LIMITED PARTS & LABOR WARRANTY MADE IN THE USA
 phone (USA and Canada): phone (international): email: online:
 1-800-940-2248 +1-636-724-3666 sales@masterclock.com www.masterclock.com

NOTE: If you are having issues running WinDiscovery using Windows 7 or Windows 8, you may need to run the software in Compatibility Mode.

- Right-click on WinDiscovery program in the Windows Start Menu, then click on [Properties].
- Select the Compatibility tab. Check the box for compatibility mode. Select WINXP SP3

Factory-default password: [public](#)

WinDiscovery Tips



Network Configuration

- Click on **[Network Configuration]** from the Device Settings window.
- Network settings must be established for the clock to operate on the network.
- To use a static IP address, de-select the checkbox for “Automatically obtain network configuration from DHCP/BOOTP”. You must enter the IP address, netmask, gateway, primary DNS and also a secondary DNS.


MASTERCLOCK INC. 5-YEAR LIMITED PARTS & LABOR WARRANTY MADE IN THE USA
 phone (USA and Canada): phone (international): email: online:
 1-800-940-2248 +1-636-724-3666 sales@masterclock.com www.masterclock.com


- A momentary press of the reset button will display the current IP address of the unit.



Input Configuration


- The **[Input Control]** button provides access to the Input Control window, which provides buttons for NTP Client, and Time Code Reader






- Note: If the NTP server is not provided by the DHCP server, unclick the box “Use NTP server provided by the DHCP server”

The Time Code Reader will automatically detect and calibrate its automatic gain control circuit to the incoming time code signal, by default. The circuit is self-adjusting to changes in the input time code; However, you may adjust some of the calibration and detection circuit settings manually.




Output Configuration

- The **[Output Control]** button provides access to the Output Control window,




which provides buttons for Time Code Generator Output.

Select [Timecode Generation] and select either [Time Code Generator A] or [Time Code Generator B]. You may now select the SMPTE time code to generate from that channel along with any additional encoding you would like to use. The time code may be generated in Local Time, UTC, or with a custom offset.




Telnet and SNMP Configuration




- Telnet is disabled by default. To enable Telnet, under Device Setting click on **[Communications Control]** then click on **[Telnet Control]**, and click the checkbox to “**Allow Telnet Configuration**”
- To configure SNMP control, under Device Setting click on **[Communications Control]** then click on **[SNMP Control]**.

MASTERCLOCK INC. 5-YEAR LIMITED PARTS & LABOR WARRANTY MADE IN THE USA
 phone (USA and Canada): phone (international): email: online:
 1-800-940-2248 +1-636-724-3666 sales@masterclock.com www.masterclock.com




Time Zone

- To configure Time Zone offset, under Device Settings click on **[Time Zone]**. The pop-up window displays a list of time zones, including descriptions to help with the selection.



Daylight Saving Time

- To configure DST, under Device Settings, click **[Daylight Saving Time]**. Manually enter the daylight saving time rules or select a pre-configured option.




Email (SMTP) Configuration

- To set up email alerts, under Device Setting, click on **[Administrative Functions]**, then **[Email Configuration]**.

Display Options

- To adjust brightness levels or to customize date and time display, under

Device Settings click on **[Display Properties]**.



The **[Clock Control Settings]** button allows the configuration of the Multicast IP address to use along with the Port, and whether, or not to use CS-5 Encrypted packets on the network. Note: when utilizing CS-5 Encrypted packets, the Device ID of the unit is required on the receiver.

Common Configuration Questions

Static IP

- If using a static IP, make sure that under **[Input Control] - [NTP Client]** the following box is unchecked: "Use NTP server provided by the DHCP server"


MASTERCLOCK INC. 5-YEAR LIMITED PARTS & LABOR WARRANTY MADE IN THE USA
phone (USA and Canada): phone (international): email: online:
1-800-940-2248 +1-636-724-3666 sales@masterclock.com www.masterclock.com

Reset Factory Default Configuration


In some situations (such as a lost password or removal of confidential information prior to sending the unit in for maintenance or repair service) it may be necessary to return the RC1000 to its factory default configuration. A recessed button labeled “RESET”, located on the back of the unit performs this function.

To reset configuration to factory default:

1. Press and hold the “RESET” button.
2. Continue to press the “RESET” button until the unit reboots




MASTERCLOCK INC. 5-YEAR LIMITED PARTS & LABOR WARRANTY MADE IN THE USA
phone (USA and Canada): phone (international): email: online:
1-800-940-2248 +1-636-724-3666 sales@masterclock.com www.masterclock.com



RC1000-A6:CF Status

Display snapshot




UTC Time: 14:27:13 03/29/2019
 Local Time: 09:27:13 03/29/2019
 Current Reference: NTP
 Reference Status: Reference Locked
 Last Time Lock Lost (UTC): 14:08:52 03/29/2019
 Last Time Lock Restored (UTC): 14:09:38 03/29/2019
 PPS/PPM/PPH Input Source: N/A
 10 MHz Source: N/A


Network | NTP | TCR | TCG A | TCG B

Type of Time Code Being Generated
 SMPTE @30 frames per sec.
 Raw Time Code: 20:00:00:08:00:80:00:00

Time To Generate
 UTC - No Offset
 Local
 Custom

Close





Auxiliary Control

Network Control

Control Source ID (1-65535, 0 = no auxiliary control):

Multicast... IP Address: Port:

Communication Timeout (seconds): (15 - 65535, 0 = no timeout)

Time Code Control

Under RC-500/600/1000 Control

Auxiliary Control

Network Control

Control Source ID (1-65535, 0 = no auxiliary control):

Multicast... IP Address: Port:

Communication Timeout (seconds): (15 - 65535, 0 = no timeout)

Time Code Control

Under RC-500/600/1000 Control