TCR500-PCI

SMPTE - EBU & IRIG - B1

TIME CODE READER

FOR PCs



2484 West Clay St. Charles, MO 63301 Phone: (636) 724-3666 Fax: (636) 724-3776 www.masterclock.com

TABLE OF CONTENTS

INSTRUCTION BOOK WARRANTY	A
SOFTWARE LICENSE AGREEMENT	A
License Title/Ownership	A
Grant of License	A
Copyright	A
Other Restrictions	В
U.S. Government Restricted Rights	В
General	В
INTRODUCTION	.1
HARDWARE DETAILS	.1
Input Connections	.1
Input Level	.1
Input Impedance	.2
Time Code Input Select	.2
Plug And Play	.2
SOFTWARE	
TCRSync-PRO	
Time Synchronization Service for Windows 95, 98, and Me (Millennium)	
Time Synchronization Service for Windows NT/2000/XP Differences between Windows 2000 and Windows NT	
TCRSync Configuration Utility	
TCRSync Monitor Utility	
Time Code Viewer	
TCR SDK for CUSTOM PROGRAMMING	.9
TCR Dynamic Link Library	.9
Specifications	
Time Code INPUT	0
PCI BUS1	0
Physical1	0
Operating/Storage Temperature & Humidity1	1
Compliance1	
LIMITED SOFTWARE WARRANTY1	2
30 Day Satisfaction Guarantee1	2
Limited Warranty For Next 60 Days1	2
Limitation of Remedies1	
LIMITED HARDWARE WARRANTY1	3
Exclusions1	
Warranty Limitations1	
Exclusive Remedies1	
Obtaining Hardware Service1	
FCC Compliance Statement1	4

INSTRUCTION BOOK WARRANTY

The information contained in this document is subject to change without notice.

Masterclock, Inc. (herein after Masterclock) makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

<u>Masterclock shall not be liable for errors contained herein or for incidental or consequential</u> damages in connection with the furnishing, performance, or use of this material.

SOFTWARE LICENSE AGREEMENT

Please read this License carefully before using the Software. This is a legal agreement between you (the Customer as an individual or an entity), the end user, and Masterclock, Inc. (herein after Masterclock) The right to use this Software is granted only if the Customer agrees to the terms of this License. If you do not agree to the terms of this License, promptly return the disk package and accompanying items (including written materials and binders or other containers) to the place you obtained them for a full refund.

Use of this software indicates your acceptance of these terms and conditions.

LICENSE TITLE/OWNERSHIP

No title or ownership of the Software is conferred with this License.

GRANT OF LICENSE

This Masterclock Software License Agreement ("License") permits you to use one copy of the Masterclock software product ("Software") on any single computer, provided the Software is in use on only one computer at any time. If you have multiple Licenses for the Software, then at any time you may have as many copies of the Software in use as you have Licenses. The Software is "in use" in a computer when it is loaded into the temporary memory (i.e., RAM) or is installed into the permanent memory (e.g., hard disk, CD-ROM, or other storage device) of that computer. However, a copy installed on a network server for the sole purpose of distribution to other computers is not "in use." If the anticipated number of users of the Software will exceed the number of applicable Licenses, you must have a reasonable mechanism or process in place to assure that the number of persons using the Software concurrently does not exceed the number of Licenses. If the Software is permanently installed on the hard disk or other storage device of a computer (other than a network server), then the person authorized to use such computer also may use the Software on a portable computer, laptop, and home computer. If such person's authorization to use such computer ceases for any reason (e.g. termination of employment), then such person's authority to use the software on a portable computer, laptop, and home computer shall cease.

COPYRIGHT

The Software is owned by Masterclock and is protected by United States copyright laws and international treaty provisions. Therefore, you must treat the Software like any other copyrighted material (e.g., a book or musical recording), *except* that you may either (a) make one copy of the Software solely for backup or archival purposes, or (b) transfer the Software to a single hard disk provided you keep the original solely for backup or archival purposes. You may not copy written

materials accompanying the Software. All authorized copies must bear the copyright notice on or in the original.

OTHER RESTRICTIONS

This License is your proof of license to exercise the rights granted herein and must be retained by you. You may not rent or lease the Software, but you may transfer your rights under this License on a permanent basis provided that you transfer this License, the Software and all accompanying written materials, you retain no copies, and the recipient agrees to the terms of this License. You may not decompile, or disassemble the Software. If the Software is an update, any transfer must include the update and all prior versions.

Masterclock reserves the right to terminate this License upon breach. In the event of termination at Masterclock's election, all copies of the Software must be returned to Masterclock or destroyed.

U.S. GOVERNMENT RESTRICTED RIGHTS

The Software and documentation are provided with Restricted Rights. Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software clause as DFARS 252.227-7013 or subparagraphs (c) (1), (2) and (3) of the Commercial Computer Software - Restricted Rights at 48 CFR 52.227-19, as applicable, and any amendments thereto. Contractor/manufacturer is Masterclock, Inc., 2484 West Clay St., St. Charles, MO 63301

GENERAL

This Agreement is governed the laws of the State of Illinois (except federal law governs copyrights and registered trademarks). If any provision of this Agreement is deemed invalid by any court having jurisdiction, that particular provision will be deemed deleted and will not affect the validity of any other Agreement.

INTRODUCTION

The TCR500-PCI is a time code reader plug-in cards for standard 5V, 32 bit PCI bus, on IBM-PC's and compatible computer systems. The card can be used to synchronize time in a PC or Server to a master time code. In addition, it can be used as a SMPTE or IRIG-B(1) linear time code reader, under software control. The reader is compatible with 24/25/30 fps NDF (Non Drop Frame) SMPTE linear time code. The reader is also compatible with the IRIG-B(1) 1 kHz amplitude modulated time code format.

This instruction book covers installation and operation of the card using linear SMPTE and also IRIG-B(1) TC (Time Code). In some cases references are made to 24, 25 or 30 frames. It should be understood that the reference to 24, 25 or 30 frames per second only applies to the SMPTE TC.

Masterclock, Inc. provides the following on the CD which ships with the TCR card:

- Card drivers for the following operating systems: Windows 95, 98, 98SE, Me (Millennium), NT 3.51/4.0, 2000 & XP.
 - TCRSync-PRO An advanced time synchronization software package providing time zone offset capabilities, automatic daylight savings time handling, unobtrusive background operation functionality, and many other high-end features.
- Time Code Viewer A time code display/diagnostic utility.
- An API (application programming interface) library with documentation and example code.

Available for separate purchase is:

• TCRSync-NTP – Integrates with TCRSync-Pro for provide enterprise-level network time synchronization utilizing the open standard NTP (network time protocol). Available for Windows 2000/XP.

HARDWARE DETAILS

INPUT CONNECTIONS

The TC input is balanced; as such the input polarity is not critical to operation of the TCR card. However, for systems distributing single ended or unbalanced TC signal to multiple drops (multiple TC devices), it is suggested that the signal distribution method be consistent.

An insulated BNC female connector is provided as a standard connector for 2-wire time code input. By convention, Masterclock systems utilizing a BNC connector and coaxial cable to distribute time code reserve the center conductor of the BNC as the Time Code signal and the outer BNC conductor as the Time Code Reference/Signal GND

INPUT LEVEL

The input level is controlled via an automatic gain control circuit. The TCR firmware will automatically determine the appropriate gain control setting for your incoming time code dB level.

The TCR cannot adjust for time code signal levels outside the range of -15 and +20dB. The card requires up to 30 seconds to complete automatic gain control when decoding SMPTE and (in the worst

case) up to three minutes when decoding IRIG-B(1). When proper gain control has been achieved the incoming time code should be read and displayed on the screen without any hesitations or jumps, and the LED on the card will light steady-on.

INPUT IMPEDANCE

The input impedance for the Masterclock TCR circuit is considered to be relatively high at approximately >100kOhm. This high input impedance allows for connecting multiple Masterclock TCR load devices without loading and/or distorting the time code input signal.

TIME CODE INPUT SELECT

All TCR500-PCI cards require a jumper configuration to set which type of time code will be decoded - SMPTE or IRIG-B(1). The jumper is J1 on the TCR500-PCI. The jumper should be placed in the off (open) position for SMPTE decoding (factory default setting), and the on (closed) position for IRIG-B(1) decoding.

PLUG AND PLAY

The TCR500-PCI is fully plug and play compatible. Windows (with the exception of NT) will detect this card on the next system boot, automatically configure appropriate I/O port and interrupt settings, then prompt for the driver.

SOFTWARE

The CD that ships with your TCR card includes a set of software tool programs for use with the TCR card on the Windows 95/98/ME/NT/2000/XP platforms. Please refer to the TCR500-PCI Installation Guide located in the documentation directory on the CD for information on installing the drivers and software tools.

TCRSYNC-PRO

TCRSync-PRO is specifically designed for the TCR500 card to synchronize time in a PC Workstation, or Server to a master time code input. TCRSync-PRO consists of the following:

- TCRSync Service
- TCRSync Configuration Utility
- TCRSync Monitor Application

Time Synchronization Service for Windows 95, 98, and Me (Millennium)

All three platforms are fully supported by the TCRSyc service [Sync95.exe] which is run as a service.

Time Synchronization Service for Windows NT/2000/XP

Both the Windows NT 3.51 and 4.0 operating systems are fully supported and the software installation procedures for both are identical. For the remainder of this manual both operating system versions will be referred to as "Windows NT".

Differences between Windows 2000 and Windows NT

Windows 2000 is the next generation of Microsoft's Windows NT (New Technology) platform. Where appropriate, this manual will discuss installation issues specific to users of the Windows 2000 or Windows NT platform.

A new feature to Windows 2000/XP networking is the Win32 Time ("*W32Time*") native computer-tocomputer time synchronization mechanism. For TCRSync to operate properly *W32Time* must be configured in specific ways depending on the network environment. A more detailed discussion of this topic is found in the section entitled <u>Windows 2000 and W32Time Services</u>. TCRSync-Pro installation will assist you in configuring *W32Time* services appropriately.

TCRSync Configuration Utility

A TCRSync Configuration applet is installed into the Control Panel by TCRSync installation utility, or the utility can be accessed from the Masterclock\TCR500 program group by using the start menu button.

The TCRSync Configuration Utility should be run to configure your TCR card and software parameters for your source of time code input and your system setting. This configuration utility prompts you for information regarding your source of time code and various clock synchronization operating parameters. When configuration is changed, you may be prompted to restart the Windows system for the changes to take effect. Always restart when prompted.

If an error made during installation and is not discovered until after installation has completed, the installation program does not have to be re-run to change the configuration. Run the *TCRSync* Utility to reconfigure for the correct parameters.

Т	CRSync Professional - version 1.1	×
	TCRSync-PR0 Configuration Change synchronization settings such as time code source, time conversion, and date availability.	
	Apply Cancel	

Select your time code source from the available options and follow the on screen display.



Time Code Source

- *Masterclock, Inc. GPS100 master clock* choose this option if your time code source is the GPS100 master clock. When you choose this time code source options normally presented in the <u>Incoming Time Code Configuration</u> dialog are automatically determined.
- *Masterclock, Inc. GPS200/200A master clock* choose this option if your time code is being applied to the computer by one of these master clocks.
- *Masterclock, Inc. TCO100 Time Code Oscillator* choose this option if your time code is being applied to the computer by one of these master clocks.
- *Masterclock, Inc. TCI232* choose this option if your time code is being applied to the computer by one this MC time code converter product.
- *Masterclock, Inc. TCI232A/TCI500* choose this option if your time code is being applied to the computer by one of these MC time code converter products.
- *Other* choose this option if your time code source is not listed.

GPS100/200/200A Time Code	Options			
e I	PS-100/200 Time Code Options X Select the GPS-100/200 support options you would like enabled: X Allow time synchronization during freewheeling (recommended) Display warning during freewheeling (recommended) <<<			
This dialog appears only if you have selected the GPS100/200/200A as your time code source.				
 synchronization if the GPS1 manual for more informatio <i>Display warning during free</i> 	<i>during freewheeling</i> - check this option if you want to allow time 100/200 is "freewheel" generating time code. See the GPS100/200 on on freewheel time code generation. <i>ewheeling</i> - check this option if you want a message to be logged when leaves freewheel time code generation mode.			

Incoming Time Code Configuration

This dialog appears unless you select the GPS100 as your time code source.

2	Date information encoded in time code
Г	Time/Date in time code is adjusted for daylight savings time (during DST)
e	UTC (GMT)
с	Other (select time zone below)
Sel	lect Time Zone:
(G (G (G	MT+13:00) Nuku'alofa MT+12:00) Fiji, Kamchatka, Marshall Is. MT+12:00) Auckland, Wellington MT+11:00) Magadan, Solomon Is., New Caledonia MT+10:00) Guam, Port Moresby

- Date information encoded in time code check this option if the time code source encodes date information. For SMPTE-type time codes, the date must be encoded to the Leitch[™] specification. For IRIG-B time code, the date must be encoded within the IEEE 1344 specification. [Note: date support for IRIG-B under IEEE 1344 requires TCR500 time code reader firmware version 1.6 or later, or TCR500-PCI card. Consult TCR500 manual for information on determining firmware version.]
- *Time/Date in time code is adjusted for daylight savings time (during DST)* check this option if your time code time/date information is adjusted for daylight savings time (during DST) to some time zone standard. This option is available only if the selected time zone reference defines daylight savings time and the *Date information encoded in time code* option is checked.
- Select time zone check UTC if your incoming time code is referenced to UTC/GMT, select Other if it is not. If Other is selected a time zone must be chosen from the time zone list box. Select the time zone that matches the reference of your time code source. This is not necessarily your local time zone. If the selected time zone defines daylight savings time, the start and end of daylight savings time will be displayed below the time zone selection list box. You may select a time zone that defines daylight savings time even if your time code source does not adjust for daylight savings time.

After selecting and configuring your time code input information, you can select an additional pop-up notification to indicated time code loss in excess of 3 minutes.



Windows 32Time service will be disabled automatically.

Windows 2000 & W32Tir	ne	×
Install has detected that yo computer that is not a dom		RSync onto a Windows 2000
In this configuration, the W disabled. Consult the TCR		
Ready to disable the W32	l'ime time synchron	ization client now?

Regarding Windows 2000 AND W32Time Services

W32Time is a time synchronization service, which is installed and operational by default on Windows 2000 computers. Depending on the network role for a Windows 2000 computer, which is running TCRSyncPro, it may be necessary to reconfigure the W32Time service. There are two primary scenarios of interest:

Windows 2000 Workstation/Server

In this environment W32Time will act as a client and attempt to synchronize time to a Windows 2000 domain controller, if one is available. When TCRSyncPro is installed in this environment it will not be able to keep time synchronized properly if W32Time is also attempting to synchronize time. In this scenario, W32Time must be disabled. TCRSyncPro installation will prompt to disable W32Time during installation.

Windows 2000 Domain Controller

By default, W32Time acts as a time "master" when operating on a Windows 2000 server in the role of domain controller. In this scenario it is OK to disable the W32Time service but is it is recommended that that W32Time be reconfigured such that the time on the domain controller is "trusted time". The time is trusted because it is being provided by TCRSync from a stable and accurate external time code reference. TCRSyncPro installation will offer to reconfigure W32Time on a domain controller so that it can then offer this trusted time to other computers on the network.

More W32Time Information

The following Microsoft knowledge base articles discuss various configuration options and behavioral aspects of the W32Time time synchronization mechanism: Q223184, Q245129, Q216734, Q240365, Q224799, and Q232209.

Follow the prompts to complete the configuration and reboot your system.

estart System?	<u>×</u>
Your system configuration has cha for these configuration changes to	anged. The system must be restarted) take effect.
Do you want to re	start the system now?
Reboot System	Don't Reboot System

TCRSync Monitor Utility

The *TCRSync Monitor* program is provided to help troubleshoot a TCRSync installation as well as display general information about time synchronization activity.

Service version:		
lime Code	- Time: 20:18:11	Date: 03/19/2004
лтс	20:18:11	Fri, Mar 19, 2004
.ocal	14:18:11	Fri, Mar 19, 2004
(S)20:11:30.00 (S)20:12:29.99	history: 3 03/19/2004 <- (T)20 1 03/19/2004 <- (T)20 7 03/19/2004 <- (T)20	:11:23.001 03/19/2004 :11:30.001 03/19/2004 :12:30.001 03/19/2004 :13:25.001 03/19/2004
HEALTHY Synchronization [S]20:11:23.20i (S]20:11:30.00i (S]20:12:29.99i (S]20:13:25.00i (S]20:13:51.00i (S]20:13:51.00i (S]20:14:53.01i	history: 03/19/2004 <- (T)20 03/19/2004 <- (T)20 03/19/2004 <- (T)20 03/19/2004 <- (T)20 03/19/2004 <- (T)20 03/19/2004 <- (T)20 03/19/2004 <- (T)20	:11:30.001 03/19/2004

When executed *TCRSync Monitor* will, by default, attempt to establish communication with TCRSync time synchronization on the local computer. If Monitor cannot communicate with a local installation of TCRSync you will be prompted to specify a remote computer on which TCRSync time synchronization has been installed. See the troubleshooting tips section if Monitor is unexpectedly failing to communicate with a local installation of TCRSync. [Note: Monitor may only remotely monitor a TCRSync installation if that installation is running on Windows 2000/XP.]

By clicking the ? icon on the Monitor title bar then clicking on an item in the dialog you can obtain online help information about a particular item in the dialog.

TIME CODE VIEWER

Time Code Viewer is a time code display and diagnostic utility. It can be used to view time code (when decoding is active) and determine other operational characteristics of the TCR card such as signal calibration.

Time Code Viewer displays raw time as decoded by your TCR card. You can use this program to easily determine if SMPTE time code contains the date encoded to the LeitchTM specification by checking the Leitch Date Decode option. If a valid date appears in the date decode box then you have date information available that TCRSync can use to synchronize your Windows system.

📲 Time Code Viewer (SMPTE)	×
Time: 20:16:54/22	User groups: 08 09 03 01 04 04 00 00	
✓ Leitch-format date en → Date:	coded in user groups	
03/19/04		
Recalibrate	About	

Time Code Viewer might display one of the following indications instead of time code:

- No Time Code Time code is not available (but was available at some previous time).
- Calibration In Progress Time code has not been available since the computer was started and the card is currently searching for it. You will also receive this message temporarily if the "Recalibrate" option is selected during normal operation.

Time Code Viewer (Calibrating)	×
Time: Calibration in progress	

Either of the above statuses indicates that there is a problem with the time code source. Refer to the *TCR500 troubleshooting guide* for problems with the time code source.

Time Code Viewer can also display IRIG-B1 time code if TCRSync has been installed to decode that type of time code. If your IRIG-B1 time code source implements IEEE 1344 encoding extensions this information can also be displayed by checking the appropriate box. Note: do not use this function to attempt to empirically determine if your IRIG-B1 contains IEEE 1344 encoding. This is not reliable due to the composition of the standard. Instead, refer to documentation for your IRIG-B1 master clock system.

🖁 Time Code Viewer (I	RIG-B1) X
Time: 20:18:04	Day
✓ IEEE 1344 specification	on encoded in control functions
Date:	
March 19, 2004	-1.0 hours
- Leap Second:	Quality:
Pending: NO	Precision: Normal/Locked
Status:	Parity: OK
- Daylight Time:	
Pending: NO	
Status: YES	

Time Code Viewer cannot run if the TCR device driver failed to load. *Time Code Viewer* utility <u>does not</u> monitor time synchronization. Use *TCRSync Monitor* for that task.

TCR SDK FOR CUSTOM PROGRAMMING

The TCR SDK contains an application programming interface (API) to the TCR DLL. It runs on all the Windows platforms. The API can be linked to and called from custom Windows applications to provide specialized handling of time code, and for integration into OEM-level applications. The API includes programmer's documentation, libraries, and sample applications for MS Visual C++. To intall the TCR SDK, select the *Custom* option when installing (See the installation guide). Note: Support for custom applications, OEM, and software development with the TCR is not provided by Masterclock. Information, libraries, and sample code is provided as-is.

TCR DYNAMIC LINK LIBRARY

The TCR Dynamic Link Library (DLL) is a library that is used by Windows programs to access the TCR500 driver.

SPECIFICATIONS

TIME CODE INPUT

Туре	Longitudinal Time Code (LTC), forward running
SMPTE/EBU/Film	
Date encoding (User Bits)	to Leitch/Masterclock Encoding

NOTE: The use of this device with time code generators providing SMPTE drop frame (DF) time code may cause undesireable operation when using the TCRSync service for setting the computer date/time. Use only (NDF) linear/longitudinal time code. NOTE: The use of this device with time code generators providing date encoding or other data in the user bit fields, other than to the Leitch/Masterclock date encoding standard, may cause undesireable operation.

IRIG-B1 (Amplitude Modulated, 1kHz)

B120	BCD, CF to IEEE-1344 or zero filled, No SBS or zero filled
B121	BCD, CF to IEEE-1344, No SBS (zero filled)
B122	BCD, No CF (zero filled), No SBS (zero filled)
	BCD, No CF (zero filled), No SBS or zero filled

NOTE: This unit does not read the optional SBS information, this information will be ignored/treated as zero filled. NOTE: This unit does not read CF, except to IEEE-1344 specification for date/year encoding. (See tcr500.sdk for details) NOTE: The use of this device with time code generators providing CF information that is not to IEEE-1344, or using SBS information may cause undesireable operation when using the TCRSync service for setting computer date/time.

Connector (Standard)	. BNC (P2), isolated
Input Impedance	. High, >100 kOhm

PCI BUS

Voltage	. 5V
Speed	
¥ Width	
	,

PHYSICAL

Height	
Length	
PCI Bracket(s)	



NOTE: Not actual size

OPERATING/STORAGE TEMPERATURE & HUMIDITY

- Operating Temperature0 to +40°C
- Relative Humidity Up to 90% (non condensing @ 25°C)
- Relative Humidity Up to 90% (non condensing @ 25°C)

COMPLIANCE

Radiated Emissions Class A, FCC Part 15, digital device

LIMITED SOFTWARE WARRANTY

To the original customer only, Masterclock, Inc. (hereinafter Masterclock) provides the following Limited Warranty.

30 DAY SATISFACTION GUARANTEE

For thirty (30) days after date of delivery of the SOFTWARE to you, if you are dissatisfied with the SOFTWARE for any reason you may return the complete product, with your receipt, to Masterclock, postage prepaid, during the thirty (30) day period for a full refund.

LIMITED WARRANTY FOR NEXT 60 DAYS

C&A warrants that for the sixty (60) days following the initial thirty day period, as evidenced by a copy of your receipt, that:

(1) The SOFTWARE will perform substantially the functions described in the documentation provided by Masterclock

(2) The media on which the SOFTWARE is furnished will be free from defects in materials and workmanship under normal use.

Your sole remedy under the warranty during this sixty (60) day period is that Masterclock will undertake to correct within a reasonable period of time any reported "SOFTWARE Error" (failure of the SOFTWARE to perform substantially the functions described in the documentation), correct errors in the documentation, and replace any magnetic media which proves defective in materials or workmanship on an exchange basis without charge. In order to make a claim under this warranty you must return the defective item with your receipt to Masterclock, postage prepaid, within ten (10) days after the warranty period. If Masterclock is unable to replace defective media or if Masterclock is unable to provide corrected SOFTWARE or corrected documentation within a reasonable time, Masterclock will, at its sole and exclusive option, either replace the SOFTWARE with a functionally equivalent program at no charge to you or refund the license fee of the SOFTWARE. These are your sole and exclusive remedies for any breach of warranty during this sixty (60) day period.

Masterclock does not warrant that the SOFTWARE will meet your requirements that operation of the SOFTWARE will be uninterrupted or error-free, or that all SOFTWARE errors will be corrected. Masterclock is not responsible for problems caused by changes in the operating characteristics of computer hardware or computer operating systems which are made after the release of the SOFTWARE nor for problems in the interaction of the SOFTWARE with non-Masterclock software. Masterclock will have no responsibility to replace or refund the license fee of media damaged by accident, abuse or misapplication.

THE ABOVE WARRANTIES ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, WHETHER EXPRESSED OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON INFRINGEMENT. NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY MASTERCLOCK, ITS EMPLOYEES, DISTRIBUTORS, DEALERS OR AGENTS SHALL INCREASE THE SCOPE OF THE ABOVE WARRANTIES OR CREATE ANY NEW WARRANTIES.

SOME STATES DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, SO THE ABOVE EXCLUSION MAY NOT APPLY TO YOU. IN THAT EVENT, ANY IMPLIED WARRANTIES ARE LIMITED IN DURATION TO NINETY (90) DAYS FROM THE DATE OF

DELIVERY OF THE SOFTWARE. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

LIMITATION OF REMEDIES

REGARDLESS OF WHETHER ANY REMEDY SET FORTH HEREIN FAILS OF ITS ESSENTIAL PURPOSE, IN NO EVENT WILL MASTERCLOCK BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INDIRECT OR SIMILAR DAMAGES, INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF DATA OR BUSINESS INFORMATION (OR OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF OR INABILITY TO USE THE SOFTWARE OR ANY DATA SUPPLIED THEREWITH EVEN IF MASTERCLOCK OR ANYONE ELSE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR FOR ANY CLAIM BY ANY OTHER PARTY.

SOME STATES DO NOT ALLOW THE LIMITATION OR EXCLUSION OF LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

IN NO CASE SHALL MASTERCLOCK'S LIABILITY EXCEED THE PURCHASE PRICE FOR THE SOFTWARE.

LIMITED HARDWARE WARRANTY

Masterclock, Inc. (hereinafter Masterclock) product warranty extends to the original purchaser.

Masterclock warrants all electronic hardware products against defects in materials and workmanship for a period of one year from date of sale. If Masterclock receives notice of such defects during the warranty period, Masterclock will, at its option, either repair or replace products, which prove to be defective.

Should Masterclock be unable to repair or replace the product within a reasonable amount of time, the customer's alternate remedy shall be a refund of the purchase price upon return of the product to Masterclock. This warranty gives the customer specific legal rights. Other rights, which vary from state to state or province to province, may be available.

EXCLUSIONS

The above warranty shall not apply to defects resulting from improper or inadequate maintenance by the customer, customer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product or improper site preparation and maintenance (if applicable).

WARRANTY LIMITATIONS

MASTERCLOCK MAKES NO OTHER WARRANTY, EITHER EXPRESSED OR IMPLIED, WITH RESPECT TO THIS PRODUCT. MASTERCLOCK SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

In any state or province which does not allow the foregoing disclaimer, any implied warranty of merchantability or fitness for a particular purpose imposed by law in those states or provinces is limited to the one-year duration of the written warranty.

EXCLUSIVE REMEDIES

THE REMEDIES PROVIDED HEREIN ARE THE CUSTOMER'S SOLE AND EXCLUSIVE REMEDIES. IN NO EVENT SHALL MASTERCLOCK BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY.

In any state or province which does not allow the foregoing exclusion or limitation of incidental or consequential damages, the customer may have other remedies.

OBTAINING HARDWARE SERVICE

When returning any Masterclock hardware product for warranty repair please contact the factory for return authorization before returning the item. When you return your hardware product to Masterclock for service, you must prepay all shipping charges, duty, and taxes. Except for products returned by the customer from another country, Masterclock shall pay for return shipment of products to the customer.

FCC COMPLIANCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a commercial installation. This equipment generates, and can radiate radio frequency energy and, if not installed and used in accordance with standard installation procedures and instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case, the user will be required to correct the interference at the user's own expense.